







The buttons are protected by a transparent and water-repellent epoxy material which protects the keyboard from water, chlorine and mechanical stress, as well as faciliting cleaning .